



# BOLDTRAK 'S' Fold Tape Guide #

3 Piece System

ONE WAY DRAW	
Rod Length	Snap Tape & Pendants
1000	20
1125	22
1250	26
1375	28
1500	30
1625	32
1750	34
1875	38
2000	40
2125	42
2250	44
2375	46
2500	48
2625	50
2750	54
2875	56
3000	58
3125	60
3250	62
3375	64
3500	68
3625	70
3750	72
3875	74
4000	76
4125	78
4250	82
4375	84
4500	86
4625	88
4750	90
4875	94
5000	96
5125	98
5250	100
5375	102
5500	104
5675	108
5750	110
5875	112
6000	114

CENTRE CLOSE	
Rod Length	Snap Tape & Pendants
1000	2 x 12
1125	2 x 12
1250	2 x 14
1375	2 x 14
1500	2 x 16
1625	2 x 18
1750	2 x 18
1875	2 x 20
2000	2 x 20
2125	2 x 22
2250	2 x 22
2375	2 x 24
2500	2 x 26
2625	2 x 26
2750	2 x 28
2875	2 x 28
3000	2 x 30
3125	2 x 32
3250	2 x 32
3375	2 x 34
3500	2 x 34
3625	2 x 36
3750	2 x 36
3875	2 x 38
4000	2 x 40
4125	2 x 40
4250	2 x 42
4375	2 x 42
4500	2 x 44
4625	2 x 46
4750	2 x 46
4875	2 x 48
5000	2 x 48
5125	2 x 50
5250	2 x 50
5375	2 x 52
5500	2 x 54
5675	2 x 54
5750	2 x 56
5875	2 x 56
6000	2 x 58

# These calculations have allowed for suitable cover &/or overlap however the elasticity of the fabric, or memory, is critical in determining actual quantities required. Contact Vanda for further information on quantities

Not all fabrics are suitable for 'S' Fold headings and a trial piece should be made to check suitability

### Calculate Fabric Requirement

- 100% fullness
- Take the number of snaps for rod length above
- Multiply this number by 108mm (distance between stud centres)
- Total is tape length and minimum amount of fabric required